


## SafeTravel

DK\_Låsen er fabriksindstillet til at åbne ved 000.

Du kan bevare denne kombination som din egen kode, eller vælge din personlige kode således:



1. Drej låsebøjlen væk fra låsen og tryk den nedad.
2. Indstil din personlige kode og løft låsebøjlen opad, og drej den om og ned i låsen. Fjern din personlige kode fra skalaen, og låsen er aktiveret.
3. Når låsen skal åbnes, indstiller du igen din personlige kode, og låsen kan åbnes. Hvis du igen ønsker at ændre din personlige kode, følger du trin 1 og 2 igen.

NO\_Låsen er fabrikkinnstilt til å åpnes med kode 000.

Du kan bruke denne kombinasjonen, eller velg din personlige kode på følgende måte:

1. Vri låsearmen bort fra låsen og trykk den ned.
2. Still inn din personlige kode og løft låsespaken oppover og skru den ned i låsen. Fjern din personlige kode fra skalaen og koden er lagret.
3. Når låsen skal åpnes, bruk din personlige kode og låsen kan åpnes. Hvis du vil endre din personlige kode, følger du trinn 1 og 2 igjen.

GB\_The lock is set at the manufacturer to open at 000.

You can keep it as your own combination, or set a new one as following steps:

1. Turn the locking bracket away from its hole position and press it down.
2. Set your personal code and lift and turn the locking bracket into its hole-position and press down. Remove your personal code and the lock is activated.
3. When opening the lock again set your code, and the lock can be opened. If you want to change your code again, follow step 1 and 2 again.